680.080 **FOOD DRYING OVEN -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZCE220-1081	Power Cord	1
2	ZCE220-1082	Block Terminal	1
3	ZCE220-1083	Rear Board	1
4	ZCE220-1084	Fan Assembly 12W	1
5	ZCE220-1085	Thermostat 75°C	1
6	ZCE220-1086	Insulation Plate	1
7	ZCE220-1087	Right Rack Assembly	5
8	ZCE220-1088	Timer 12H	1
9	ZCE220-1089	Temperature Limiter	1
10	ZCE220-10810	Thermostat Holding Plate	1
11	ZCE220-10811	Heating Element Assembly 900W	1
12	ZCE220-10812	Shell	1
13	ZCE220-10813	Foot	4
14	ZCE220-10814	Tray	10
15	ZCE220-10815	Quarries Net	1
16	ZCE220-10816	Front Panel	1
17	ZCE220-10817	Handle	1
18	ZCE220-10818	Left Rack Assembly	5
19	ZCE220-10819	Top Board	1
20	ZCE220-10820	Control Board Plate	1
21	ZCE220-10821	Switch	1
22	ZCE220-10822	Knob Of Timer	1
23	ZCE220-10823	Knob Of Thermostat	1