688.175 **PIZZAOVEN** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZCE220-1181	Timer	1
2	ZCE220-1182	Front Frame Of Inner Cabinet	1
3	ZCE220-1183	Sensor Plate	2
4	ZCE220-1184	Lamp Cover	2
5	ZCE220-1185	Upper Plate Of Inner Cabinet	1
6	ZCE220-1186	Lamp	2
7	ZCE220-1187	Temperature Limitor	1
8	ZCE220-1188	Wind Board	1
9	ZCE220-1189	Thermostat Rack	1
10	ZCE220-11810	Power Cord	1
11	ZCE220-11811	Terminal	1
12	ZCE220-11812	Wire Cord	1
13	ZCE220-11813	Shell	1
14	ZCE220-11814	Fan	1
15	ZCE220-11815	Upper Plate Of Foaming	1
16	ZCE220-11816	Cover Of Wind Board	1
17	ZCE220-11817	Fan Rack	1
18	ZCE220-11818	Rear Board	1
19	ZCE220-11819	Foaming Insulation	1
20	ZCE220-11820	Rear Plate	2
21	ZCE220-11821	Heating Element	3
22	ZCE220-11822	Right Heating Element Rack	2
23	ZCE220-11823	Heating Element Rack	2
24	ZCE220-11824	Lower Heating Element Rack	1
25	ZCE220-11825	Pizza Stone	2

688.175 **PIZZAOVEN -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
26	ZCE220-11826	Left Heating Element Rack	2
27	ZCE220-11827	Back Plate Of Inner Cabinet	1
28	ZCE220-11828	Supportor Of Inner Cabinet	4
29	ZCE220-11829	Right Plate Of Inner Cabinet	1
30	ZCE220-11830	Foot	4
31	ZCE220-11831	Bottom Plate	1
32	ZCE220-11832	Bottom Plate Of Inner Cabinet	1
33	ZCE220-11833	Hinge	2
34	ZCE220-11834	Lower Rack Of Inner Cabinet	1
35	ZCE220-11835	Inner Door Plate	1
36	ZCE220-11836	Inner Glass Plate	2
37	ZCE220-11837	Inner Glass	1
38	ZCE220-11838	Front Door Frame	1
39	ZCE220-11839	Inner Door Upper Plate	1
40	ZCE220-11840	Middle Rack Of Inner Cabinet	1
41	ZCE220-11841	Outer Glass	1
42	ZCE220-11842	Handle	1
43	ZCE220-11843	Space Supporter	2
44	ZCE220-11844	Control Panel	1
45	ZCE220-11845	Inner Cabinet	1
46	ZCE220-11846	Thermostat Knob	2
47	ZCE220-11847	Switch	2
48	ZCE220-11848	Left Plate Of Inner Cabinet	1
49	ZCE220-11849	Thermostat	1