

688.242 **PASTA COOKER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZCE700-102K1	BOARDING	1
2	ZCE700-102K2	FORTIFIED PLATE	1
3	ZCE700-102K3	TEMPERATURE LIMITER (135°C)	3
4	ZCE700-102K4	BACK SEAL PLATE	1
5	ZCE700-102K5	POWER CORD	1
6	ZCE700-102K6	SMALL FIVE EYE TERMINAL	1
7	ZCE700-102K7	INDICATOR LAMP-GREEN	3
8	ZCE700-102K8	INDICATOR LAMP-YELLOW	3
9	ZCE700-102K9	KNOB WITH BEZEL	3
10	ZCE700-102K10	THERMOSTAT (110°C)	3
11	ZCE700-102K11	VALVE	3
12	ZCE700-102K12	OUTLET FOR WATER	3
13	ZCE700-102K13	SEPARATED SLAG NET ASSEMBLY	1
14	ZCE700-102K14	FRONT BAFFLE PLATE FOR WATER TANK	1
15	ZCE700-102K15	WATER STOP SHEET	3
16	ZCE700-102K16	WATER TANK	1
17	ZCE700-102K17	HEAT ELEMENT LEFT	3
18	ZCE700-102K18	BACK PLATE FOR WATER TANK	1
19	ZCE700-102K19		1
20	ZCE700-102K20	SEPARATED MESH	1
21	ZCE700-102K21		4
22	ZCE700-102K22	RUBBER FOOT	4
23	ZCE700-102K23	BOTTOM PLATE	1
24	ZCE700-102K24	PASTA COOKER BASKET	4