

712.050 **ICE CREAM MAKER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZBC910-1001	Cover	1
2	ZBC910-1002	Cap	1
3	ZBC910-1003	Blade	1
4	ZBC910-1004	Scoop	1
5	ZBC910-1005	Screw for beater	1
6	ZBC910-1006	O-ring for screw	1
7	ZBC910-1007	Beater blade	1
8	ZBC910-1008	Beater	1
9	ZBC910-1009	Beater cover	1
10	ZBC910-10010	O-ring	1
11	ZBC910-10011	Beater shaft	1
12	ZBC910-10012	Seals of center rod	1
13	ZBC910-10013	Cylinder	1
14	ZBC910-10014	Center rod of cylinder	1
15	ZBC910-10015	Feed tube	1
16	ZBC910-10016	O-ring of Drain plug	2
17	ZBC910-10017	Drain plug	1
18	ZBC910-10018	Beater motor fixing plate	1
19	ZBC910-10019	Gear motor	1
20	ZBC910-10020	Foaming board	1
21	ZBC910-10021	Pin screw	1
22	ZBC910-10022	LED light	1
23	ZBC910-10023	U-shaped board	1

712.050 **ICE CREAM MAKER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
24	ZBC910-10024	Condenser	1
25	ZBC910-10025	Fan	1
26	ZBC910-10026	Top cover pin	1
27	ZBC910-10027	Top cover detection switch	1
28	ZBC910-10028	Compressor	1
29	ZBC910-10029	Top cover plate	1
30	ZBC910-10030	Pillar	1
31	ZBC910-10031	Bottom plate	1
32	ZBC910-10032	Front panel	1
33	ZBC910-10033	Power switch	1
34	ZBC910-10034	Display board	1
35	ZBC910-10035	Filter	1
36	ZBC910-10036	Top cover fixing seat	1
37	ZBC910-10037	Power box	1
38	ZBC910-10038	Motherboard	1
39	ZBC910-10039	Cover of power box	1
40	ZBC910-10040	Leg	4